

Powered Stacker

Removal from Pallet- Instructions

1. Locate suitable lifting straps and ensure they are in good condition.
2. Loop straps around lifting bar on top of the Stacker using a step stool or rolling ladder.
3. Secure straps to forks.
 - a. Have driver raise forks to the height of lifting bar.
 - b. Slide end of straps around each fork.
 - c. Move forklift forward so straps are at least 1/3 onto forks.
 - d. Tilt forks up and raise forks until all slack is removed from straps.
4. Clear area around Stacker.
 - a. Check that the Stacker wheel brake is set.
 - b. Make sure all helpers and objects are out of the way of the forklift.
5. Lift stacker 6 inches off the pallet.
6. Move forklift backwards away from the pallet to an open area.
7. Lower forks and set Stacker carefully on level ground.
8. Carefully remove straps from top of Stacker before using.

*Caution: Do not stand next to forklift outriggers.