


**ULINE** H-1267

**CORDLESS BARCODE  
SCANNER**

1-800-295-5510  
uline.com



## INSTRUCTIONS

1. Connect cradle to host interface. (See Figure 1)
2. Plug adapter into power source and to base station.
3. Place scanner on the cradle and charge prior to using it.
4. Scan the appropriate barcode from original Configuration Guide included in the box.

Figure 1

