


ULINE H-1787
FOLDING HAND TRUCK
100 LB. CAPACITY

1-800-295-5510
uline.com


Pour le français, consulter la page 2.



OPERATING INSTRUCTIONS


1. Position the truck as shown. (See Figure 1)

Figure 1




3. By pulling down the noseplate, both wheels will automatically extend out. (See Figure 3)

Figure 3




2. To extend handle, press top button and pull up handle. (See Figure 2)

Figure 2



4. Use bungee cord to secure cargo. (See Figure 4)


Figure 4



ULINE H-1787

CHARIOT MANUEL REPLIABLE CAPACITÉ DE 45 KG (100 LB)


1 800 295-5510
uline.ca



INSTRUCTIONS D'UTILISATION


1. Positionnez le chariot de la façon illustrée.
(Voir Figure 1)

Figure 1




3. L'abaissement de la bavette déploiera automatiquement les deux roues. (Voir Figure 3)

Figure 3



2. Pour déployer la poignée, appuyez sur le bouton supérieur et soulevez la poignée. (Voir Figure 2)

Figure 2



4. Fixez la charge avec un tendeur élastique. (Voir Figure 4)

Figure 4

