

H-812

OPERATING INSTRUCTIONS



WARNING: Always wear safety glasses which conform to ANSA Standard Z87.1 or EN 166. Position yourself to one side of the tensioned strap while sealing. Maintain proper footing and balance.

1. Fully open the sealer handles and center the open jaws on the seal. (Figure 1)
2. Bring the sealer handles completely together to assure a proper crimp. (Figure 2)




Figure 1





Figure 2

3. Remove the sealer. Cut the strap end flush with the end of the seal and inspect the seal to make sure a proper joint has been formed.
4. To avoid contact with the sharp end of the strap, retract strap end back into the strap dispenser.

SAFETY PROCEDURES FOR TOOL OPERATION

1. Before using this sealer, read all instructions included with the product.
2. Always lift and carry the tool by the tool handle knob. Lifting the tool at any other point may expose the hand to a "pinch point."
3. Make sure the sealer jaws are placed directly on the seal.
4. While sealing, position yourself to one side of the tensioned strap.
5. This tool is designed for use with grit seals and plastic strap only.
6. A properly crimped seal will appear as shown in the illustration. If the notched seal does not appear as shown, inspect the tool for worn and/or damaged parts.
7. Replace tool parts as needed.
8. Do not ship any loads secured with improperly crimped seals.



Correct Crimped Seal