
UIINI S-14803 **WAREHOUSE AISLE SIGNS**

1-800-295-5510 uline.com



ASSEMBLY INSTRUCTIONS

CONTENTS

Ten (10) plastic sign holder clips and twelve (12) sheets of heavy duty laser/ink jet compatible paper.

CLIP APPLICATION

Insert sign holder clip into standard pallet rack assembly holes-snap out to relocate. (May also be used with any shelving with 2" hole spacing.)

SIGN IMPRINTING

Using the computer program and font of your choice, you can produce a double sided 8½ x 11" sign by simply printing on the front and back side of each sheet. To create an 8½ x 5½" sign, print a portrait image on each half of the sheet, then fold.

SIGN MOUNTING

Sign holder clips are engineered to hold paper insert or plastic sign blank up to .10" Thick. Simply insert the sign into the ribbed slots. Remove by pulling the sign out vertically from the top or bottom. The sign holding mechanism is not designed to allow signs to be pulled out in the horizontal direction. The soft plastic hinge will flex to prevent breakage when sign is bumped.

OVERSIZED SIGNS

Larger signs can be mounted by using two (2) or more plastic sign holder clips.