



ULINE H-1657
SEALLESS COMBO
STRAPPING TOOL

1-800-295-5510
uline.com



ULINE H-1657

SEALLESS COMBO STRAPPING TOOL


1-800-295-5510
uline.com

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Body	1	-----	P32.2001
3	Parallel Pin	1	H-956-PPIN	N2.2187
4	Parallel Pin	1	-----	N2.2110
5	Parallel Pin	3	H-7376	N2.2188
7	Ball Bearing	2	H-956-BEAR	N3.1172
8	Needle Cage	3	H-2614-2106	N3.2106
9	Idler Gear	3	-----	P32.1217
10	Dowel	3	-----	P32.1218
11	Tensioning Wheel	1	H-2614-WHEEL	P32.1219
13	Slide-Bearing	1	-----	N3.3172
14	Feather Key	1	-----	N2.3342
15	Front Toggle Link	1	H-1728-TOGGL	P32.1050
16	Pressure Roller	1	H-2615-13	P32.1216
17	Swivel Shaft	1	-----	P32.2017
18	Holder	1	H-2614-1229	P32.1229
19	Holder	1	H-2614-1228	P32.1228
20	Slide-Bearing	3	-----	N3.3172
21	Gripper	1	H-956-1GRIPR	P32.1224
22	Gripper	1	H-956-2GRIPR	P32.1223
23	Gripper	1	H-956-GRP122	P32.1222
24	Tensioning Body	1	-----	P32.1254
25	Strap Guide	1	-----	P32.1239
26	Parallel Pin	2	H-956-PPIN	N2.2187
27	Ball Bearing	2	H-956-BEAR	N3.1172
28	Needle Cage	1	H-2615-BEAR	N3.2346
29	End Cover	1	H-956-1238	P32.1238
30	Label	1	-----	N4.9159
31	Hammer Head Bolt	2	-----	N2.4902
32	Safety Washer	6	H-7375	N1.6503
34	Parallel Pin	4	-----	N2.2189
35	Safety Washer	2	H-2615-130	N1.6505
36	Flat Head Screw	2	H-2614-32	N1.1909
37	Strap Stop	1	-----	P32.1230
38	Torsion Spring	1	H-6686	N2.5823
39	Countersunk Screw	1	H-1728-COUNT	N1.2216
40	Countersunk Screw	1	H-956-CSCREW	N1.2223
41	Screw	1	H-1332-1904	N1.1904
	Welding Gripper (Not Shown)	1	-----	P32.0153
	End Cover Assembly (Not Shown)	1	H-1657-0110	P32.0110
	Tensioning Body Assembly (Not Shown)	1	-----	P32.0136

ULINE H-1657

SEALLESS COMBO STRAPPING TOOL

1-800-295-5510
uline.com



ULINE H-1657

SEALLESS COMBO

STRAPPING TOOL

1-800-295-5510
uline.com

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
42	Type Plate	1	-----	N43.9142
43	Hammer Head Bolt	2	-----	N2.4902
44	Flat Head Screw	4	-----	N1.1952
45	Safety Washer	11	-----	N1.6504
46	Slide-Bearing	2	-----	N3.3174
47	Dowel Pin	1	-----	N2.2443
48	Fixing Plate	1	H-2614-44	P32.2023
49	Spring Slide	1	H-1333-1404	P32.1404
50	Roller	1	-----	P32.1405
51	Slide-Bearing	2	-----	N3.3174
54	Cover	1	H-2614-50	P32.2020
55	Centering Sleeve	2	-----	P32.2067
56	Lever Assembly	1	H-2614-52	P32.2026
57	Centering Sleeve	1	-----	P32.2067
58	Pressure Spring	1	H-2615-PSPNG	N2.5294
59	Spring Bolt	1	-----	P32.1403
60	Pressure Spring	1	-----	N2.5295
62	Coupler	1	-----	P32.1012
63	Pressure Spring	2	-----	N2.5157
64	Body	1	-----	P32.2001
65	Felt	1	-----	P32.1011
66	Pressure Spring	1	-----	N2.5296
67	Coupler	1	-----	P32.1410
68	Ball Cage	1	-----	P32.1027
69	Thrust Piece	1	-----	P32.1029
70	Cutter	1	H-2614-KNIFE	P32.1204
71	Pressure Spring	1	-----	N2.5237
72	Security Ring	1	H-2615-1121	N2.1121
73	Driver	2	H-6046	P32.1035
74	Driving Pin	1	-----	P32.1032
75	Seesaw Lever	1	H-1246-1249	P32.1249
76	Parallel Pin	1	H-5908-37	N2.2193
77	Guide Case	1	-----	P32.1205
79	Safety Washer	1	H-6034	N1.6504
80	Hexagon Screw	1	-----	N1.1553
81	Thrust Piece	1	-----	P32.1252
82	Coupler	1	-----	P32.1251
83	Seesaw Lever	1	H-2614-1248	P32.1248
	Spring Package Assembly (Not Shown)	1	-----	P32.0139
	Base Model Assembly (Not Shown)	1	-----	P32.0147
	Coupler Assembly (Not Shown)	1	-----	P32.1250

ULINE H-1657
SEALLESS COMBO
STRAPPING TOOL


1-800-295-5510
 uline.com

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
84	Centering Sleeve	2	-----	P32.1210
85	Centering Sleeve	1	-----	P32.1208
86	Cover	1	-----	P32.1211
87	Adhesive Label	1	-----	N41.9127
89	Pressure Spring	2	-----	N2.5178
90	Guide Pin	1	-----	P30.1156
91	Guide Pin	1	-----	P30.1162
92	Welding Stop Gripper	1	H-2614-90	P32.1203
93	Steel Insert	1	-----	P32.1201
94	Screw	2	H-6029	N1.1305
95	Safety Washer	11	H-6034	N1.6504
96	Ball	6	H-6036	N3.1702
99	Welding Gripper	1	H-2614-96	P32.1053
100	Bolt	1	H-6045	P32.1028
101	Safety Washer	6	H-7375	N1.6503
102	Screw	5	H-1332-1904	N1.1904
103	Screw	1	-----	N1.1929

ULINE H-1657

SEALLESS COMBO STRAPPING TOOL

1-800-295-5510
uline.com



#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
104	Spur Wheel	1	H-2614-2035	P32.2035
105	Ball Bearing	1	-----	N3.1160
107	Wheel	1	-----	P32.1048
108	Ball Bearing	1	-----	N3.1178
110	Ball Bearing	2	H-5908-1134	N3.1134
	Wheel Assembly (Not Shown)	1	-----	P32.0120
	Rocker Assembly (Not Shown)	1	-----	P32.0144

ULINE H-1657

SEALLESS COMBO

STRAPPING TOOL

1-800-295-5510
uline.com


#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
111	Needle Bush	2	-----	N3.2347
112	Rocker	1	H-6044	P32.1024
113	Needle Bush	2	-----	N3.2347
114	Welding Excentric	1	H-5908-1022	P32.1022
116	Pinion	1	-----	P32.1023
119	Spacer Washer	4	-----	N1.6331
120	Spring Ring	1	-----	N2.1610
121	Countersunk Screw	3	-----	N1.2112
123	Cover	1	-----	P32.1047
124	Idle Gear	3	-----	P32.1046
125	Needle Cage	3	-----	N3.2105
126	Parallel Pin	3	-----	N2.2145
128	Insertation Part	1	H-2615-113	P32.1412
129	Parallel Pin	2	H-2615-114	N2.2122
130	Lever	1	H-2615-115	P32.1411
131	Parallel Pin	1	-----	N2.2190
133	Ball Bearing	1	H-5908-1159	N3.1159
135	Spur Wheel	1	H-2615-GEAR	P32.2016
137	Spur Wheel	1	H-2614-2036	P32.2036
138	Needle Free Wheeling	1	H-6037	N3.4509
140	Tensioning Ring	1	H-1657-140	N2.1805
142	Shaft	1	-----	P32.2034
143	Planet Shaft	1	-----	P32.1044
144	Ball Bearing	1	-----	N3.1157
145	Guide	1	-----	P32.2012
146	Parallel Pin	1	H-2615-128	N2.2119
147	Screw	1	H-2615-129	N1.1922
148	Safety Washer	1	H-2615-130	N1.6505
149	Hook	1	H-2615-131	P32.2032
150	Spacer Piece	1	H-1657-150	N1.6344
151	Torsion Spring	1	H-2614-146	N2.5822
152	Lever	1	-----	P32.1051
153	Body	1	-----	P32.2001
	Welding Excentric Assembly (Not Shown)	1	-----	P32.1021
	Spur Wheel Assembly (Not Shown)	1	-----	P32.0154
	Idle Step (Not Shown)	1	-----	P32.0118
	Insertation Part Assembly (Not Shown)	1	-----	P32.0140
	Base Model Assembly (Not Shown)	1	-----	P32.0147
	Spur Wheel Assembly (Not Shown)	1	-----	P32.0156

ULINE H-1657

SEALLESS COMBO

STRAPPING TOOL

1-800-295-5510
uline.com



#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
154	Flat Head Screw	4	H-6031	N1.1934
155	Flat Head Screw	1	-----	N1.1927
156	Pt-Screw	7	H-6035	N1.7211
158	Pressure Spring	1	H-1657-5153	N2.5153
159	Pressure Button	1	H-2614-2024	P32.2024
160	Adhesive Label	2	-----	N41.9160
162	Cover	1	H-1657-COVER	P32.2010
163	Insertation Part	1	H-1728-INSRT	P32.2011
	Drive Assembly (Not Shown)	1	-----	P32.0148

ULINE H-1657

SEALLESS COMBO

STRAPPING TOOL

1-800-295-5510
uline.com

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
165	Motor Assembly	1	H-1657-MOTOR	P32.2065
166	Safety Washer	11	H-6034	N1.6504
167	Cover	1	-----	N5.2702
168	Motor Housing Assembly	1	H-1657-2042	P32.2042
169	Spring Ring	1	H-2614-160	N2.1606
170	Ball Bearing	1	H-2614-161	N31.1120
171	Disk	1	H-2615-2030	P32.2030
172	Free-Wheeling	1	H-6038	N3.4520
173	Ball Bearing	2	H-2614-BEAR	N3.1137
175	Cooling Plate	1	H-2615-PLATE	P32.2064
176	Disk	1	-----	P32.2063
177	Countersunk Screw	3	H-1728-COUNT	N1.2216
178	Ball Bearing	1	H-2614-BEAR	N3.1137
180	Spur Wheel	1	H-2614-GEAR	P32.2015
182	Turning Button	2	H-2614-TB	P32.2009
183	Pt-Screw	1	-----	N1.7206
184	Micro Switch	1	H-1657-2359	N5.2359
185	Slide-Bearing	1	-----	N3.3174
186	Circuit Board Assembly	1	H-1657-2043	P32.2043
188	Ball Bearing	2	H-2614-179	N31.1118
190	Conical Gear Wheel	1	-----	P32.2018
191	Contact Plug	1	H-1657CPLUG	N51.2129
192	Slide-Bearing	1	-----	N3.3174
193	Handle Lever Assembly	1	H-2614-LEVER	P32.2006
194	Adhesive Label	2	-----	N41.9160
195	Handle Shaft	1	H-2614-186	P32.1415
196	Lever Assembly	1	H-1657-196	P32.1414
197	Security Ring	1	H-2615-RNG	N2.1118
198	Micro Switch	1	H-1657-2322	N5.2322
199	Motor Housing Assembly	1	H-1657-199	P32.2040
200	Felt	1	-----	P32.1011
201	Body	1	-----	P32.2001
	Spur Wheel Assembly (Not Shown)	1	-----	P32.0150
	Base Model Assembly (Not Shown)	1	-----	P32.0147
	Pinion Assembly (Not Shown)	1	H-2614-178	P32.0149
	Conical Gear Wheel Assembly (Not Shown)	1	-----	P32.0151