



ULINE H-2302
ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com



FORK FRAME



ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

FORK FRAME PARTS LIST


#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Fork Frame	1	-----	1000501004
2	Rock - Arm	1	-----	1000501014
3	Bushing	2	-----	0000027006
4	Split Retaining Ring	2	H-2302-4SRP	0000026001
5	Shoulder Bushing	2	-----	0000027007
6	Connecting Shaft	2	-----	1000507019
7	Bushing	4	H-2302-27005	0000027005
8	Grease Cup	2	-----	0000030002
9	Pushing Rod	2	H-2302-PUSH	1000501009
10	Long Shaft	1	H-2302LSHAFT	1000501010
11	Screw	3	-----	1000523002
12	Fixed Plate	1	-----	1000504001
13	Bushing	4	H-2302-27008	0000027008
14	Shaft	2	H-2302-FRK14	1000507004
15	Elastic Pin	4	H-2302-FRK15	0000028009
16	Shaft for Frame of Roller	2	H-3405-SFRM	1000507005
17	Frame of Roller	2	-----	1000505002
18	Shaft	2	H-2302-FRK19	1000507014
19	Elastic Pin	2	H-2302-FRK20	0000028002
20	Shaft For Load Roller	4	H-2302-FRK21	1000507015
21	Double Wheel Carrier	2	H-2302-DWCR	1000505008
22	Grease Cup	2	H-2302-FRK23	0000030002
23	Elastic Pin	4	H-2302-FRK24	0000028007
24	Washer	8	H-2302-FRK25	1000525001
25	Bearing	8	H-2652-27001	0000027001
26	Loading Roller	4	H-2302-LDRLL	1000516004

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

ELECTRIC COMPARTMENT



ELECTRIC COMPARTMENT PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Bushing	1	-----	1010213001
2	Screw	4	-----	0000023020
3	Cover of Bearing	1	-----	1000207001
4	O-Ring	1	-----	0000022001
5	Screw	8	-----	0000023030
6	Screw	4	-----	0000023034
7	Flat Washer	4	-----	0000025002
8	Spring Washer	4	-----	0000023006
9	Bearing Seat	1	-----	1000205002
10	Bearing	1	-----	1000227001
11	Bearing Washer	1	-----	1000225001
12	Rubber Bushing	2	-----	1000218001
13	Shaft	1	-----	1000201001

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

ELECTRIC COMPARTMENT PARTS LIST


#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
14	Linking Plate	1	-----	1000204001
15	Locating Block	1	-----	1000205001
16	Driving Assembly	1	-----	1000200002
17	Screw	2	-----	0000023029
18	Screw	2	-----	0000023059
19	Elastic Washer	2	-----	0000025018
20	Flat Washer	2	-----	0000025019
21	Fixed Plate For Socket Connector	1	-----	100204002
22	Distribution Box	1	-----	1000401003
23	Split Retaining Ring	2	-----	0000026001
24	Linking Plate	2	-----	-----
25	Bushing	4	H-2302-25B	1000413001
26	Linking Pin	2	H-2302-26LP	1000407001
27	Locking Plate	2	H-2302-LKPLT	1000404030
28	Screw	2	H-2302-CHSCW	0000023053
29	Fixed Shaft	2	-----	-----
30	Screw	2	H-2302-30SC	0000023027
31	Screw	2	H-2302-31SC	1000523002
32	Screw	8	-----	0000023025
33	Spring Washer	8	-----	0000023006
34	Flat Washer	8	-----	0000025002
35	Adjusting Washer	1	-----	1000404031
36	Locking Nut	10	H-2302-23005	0000023005
37	Linking Plate	2	-----	1000401007
38	Bearing	2	-----	0000027002
39	Retaining Ring	2	-----	0000026002
40	Steering Wheel Carrier	2	-----	1000401006
41	Bolt	2	-----	1000423004
42	Locking Nut	2	-----	0000024006
43	Spring	2	-----	1000431002
44	Polyurethane Spring	2	-----	1000419001
45	Bushing	4	-----	1000413002
46	Rotating Arm	2	-----	1000401008
47	Shaft End Retaining Ring	2	-----	1000426001
48	Cylindrical Pin	2	-----	1000528004
49	Screw	2	-----	1000523002
50	Bolt	2	H-2302-23035	0000023035
51	Dust Cover	4	H-2302-04023	1000404023
52	Washer	4	H-2302-25003	1000425003
53	Shaft Sleeve	2	H-2302-02005	1000402005
54	Bearing	4	-----	-----
55	Steering Wheel	2	-----	-----
56	Locking Nut	10	H-2302-23005	0000023005

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

HYDRAULIC AND ELECTRIC SYSTEM



HYDRAULIC AND ELECTRIC SYSTEM PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Left Cover	1	H-2302LFTCVR	1000403006
2	Screw With Washer	4	-----	1000423001
3	Right Cover	1	H-2302RTCVR	1000403005

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com


HYDRAULIC AND ELECTRIC SYSTEM PARTS LIST CONTINUED

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
4	Screw With Washer	2	-----	1000423003
5	Fixed Support For Left Batteries	1	-----	1000404003
6	Flat Washer	4	-----	0000023055
7	Spring Washer	4	-----	0000025010
8	Screw	4	-----	0000023020
9	Flexible Nut	6	H-2302-9FN	1000424001
10	Fixed Plate For Controller	1	-----	-----
11	Built-In Switch Cover	1	-----	-----
11	Built-Out Switch Cover	1	-----	-----
12	Screw	4	H-2302-12	0000023039
13	Flat Washer	4	-----	0000025014
14	Greasing Cup	1	-----	0000030002
15	Fixed Support For Right Battery	1	-----	1000404004
16	Nut	1	-----	0000024003
17	Horn	1	-----	1000434015
18	Flat Washer	5	-----	0000025011
19	Screw	1	-----	0000023044
20	Bolt	4	-----	0000023018
21	Spring Washer	4	-----	0000025001
22	Nut	4	-----	0000024005
23	Cap	4	-----	1000403007
24	Battery	2	H-2302-BATT	0000025001
25	Key Switch	1	H-2302-25KY	1000434025
26	DC Power Switch	1	H-2302-DC	2240434001
27	Battery Indicator	1	-----	100434025
28	Screw	2	H-2302-SCREW	0000023076
29	Flat Washer	2	-----	0000025014
30	Piston Rod	1	-----	-----
31	Dust Ring	1	H-2302-DUST	000002204
32	Seal Ring For Shaft	1	H-2302-Washr	00000220033
33	Pump Body	1	-----	-----
34	Seal Washer	1	-----	0000022005
35	Joint	1	-----	1000317002
36	O-Ring	2	-----	000002202
37	High Pressure Oil Tube	1	-----	1000317001
38	Straight Rotation Joint	1	-----	0000017001
39	Pump Hood	1	-----	1000302001
40	Screw	2	-----	0000023042
41	Pump Station Assembly	1	-----	1000300001
	Pump Assembly (Not Shown)	1	H-2302-PUMP	1000300005
43	Rubber Grommet	1	H-2302-RUBGR	1000418001

ULINE H-2302
ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

CONTROL HANDLE



ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com


CONTROL HANDLE PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Screw	2	H-2302-1	0000023008
2	Spring Washer	2	H-2302-2	0000025003
3	Left Driving Knob	1	-----	-----
4	Shaft Sleeve	2	H-2302-4	1000113002
5	Micro Switch	4	H-2302-5	1000134002
6	Lifting Button Assembly	1	H-2302-6	1000100015
7	Horn Button	1	H-2302-7	1000114001
8	Horn Button Spring	1	H-2302-8	1000131001
9	Lifting Button Assembly	1	-----	-----
10	Screw	8	H-2302-105	0000023009
11	Layer Board	1	-----	-----
12	Accelerator	1	H-2302-34003	18130701-163
13	Right Driving Knob	1	-----	-----
14	Emergency Stop Button	1	H-2302-14	1000114002
15	Emergency Stop Button Spring	1	H-2302-15	1000131002
16	Upper Part of Handle (Included with H-2302HANDLE)	1	-----	-----
17	Handle Body (Included with H-2302HANDLE)	1	H-2302-17	10000103003
18	Screw	3	H-2302-CHSCW	0000023053
19	Bolt	2	H-2302-19	0000023046
20	Spring Washer	2	H-2302-20	0000025001
21	Handle Bar Assembly	1	-----	-----
22	Air Spring	1	H-2302-AIRSP	1000121001
23	Screw	1	H-2302-23	1000123001
24	Handle Seat	1	-----	-----
25	Shoulder Harness	2	H-2302-25	1000113001
26	Shaft For Handle	1	H-2302-26	1000107001
27	Elastic Pin	1	H-2302-27	0000028003
28	Flat Washer	2	H-2302-28	0000025002
29	Spring Washer	2	H-2302-29	0000023006
30	Locking Nut	2	H-2302-23005	0000023005
31	Cover	1	-----	-----
32	Screw	2	H-2302-32	0000023045
	Handle Assembly (Not Shown)	1	H-2302HANDLE	1000100008

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com



DRIVING WHEEL PARTS LIST

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Retaining Ring	1	-----	0000026003
2	Bearing	1	H-2652-27001	0000027001
3	Flat Pin	1	-----	0000036001
4	Gear Shaft	1	-----	1000207002
5	Gear Box Body	1	-----	1000205003

ULINE H-2302

ELECTRIC PALLET TRUCK

1-800-295-5510
uline.com

DRIVING WHEEL PARTS LIST CONTINUED

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
6	Gear	1	-----	1000209001
7	Retaining Ring	1	-----	0000026004
8	Retaining Ring	1	-----	0000026005
9	Flat Pin	2	-----	0000036002
10	Washer	1	-----	0000025020
11	Motor	1	-----	1000234002
12	Screw	5	-----	0000023061
13	Bearing	1	-----	0000027009
14	Gear	1	-----	1000209002
15	Ring	1	-----	0000022007
16	Inner Gear	1	-----	1000210001
17	Bearing	2	-----	0000027010
18	Retaining Ring	1	-----	0000026006
19	O-Ring	1	-----	0000022008
20	Oil Seat Seal	1	-----	1000222001
21	Wheel	1	H-2302-DWHL	1000216001
22	Washer	21	-----	0000025006
23	Screw	10	-----	0000023062
24	Framework Oil Seal	1	-----	0000022009
25	Cover	1	-----	1000205004
26	Cylindrical Pin	2	-----	0000028008
27	Screw	11	-----	0000023063
28	Framework Oil Seal	1	-----	1000222002
29	Electromagnetic Brake	1	-----	1000234003
30	Screw	6	-----	0000023064
31	Cover	1	-----	1000205005
32	Retaining Ring	1	-----	0000026007
33	Air Plug	1	-----	1000237001
34	Seal Washer	1	-----	0000025021
35	Wiring Fix Plate	1	-----	1000237002
36	Screw	2	-----	0000023065
37	Screw	2	-----	0000023066