


# ULINE H-1870 PACKING TABLE CASTERS

1-800-295-5510  
uline.com



## PARTS



## ASSEMBLY

1. Align caster plate with holes in bottom flange of legs.
2. Caster must be turned as shown to fit inside of the channel.
3. Attach swivel casters with lock washers and nuts.

