

**ASSEMBLY**


1. Attach canopy top to frame. Refer to instructions provided with canopy. (See Figure 1)




2. Before raising canopy to extended height, fold up two adjacent corners of canopy top to reveal inside perimeter Velcro® strip. (See Figure 2)




3. Holding side wall, fold top edge of wall so Velcro® aligns with Velcro® strip sewn to canopy top. Attach Velcro® strip along top edge of canopy top, aligning zipper to outside corner of leg frame. Repeat this step until all walls are attached. (See Figure 3)



4. Attach side wall to frame with clips on top side of wall. (See Figure 4)



5. Secure Velcro® strips around each corresponding leg frame and zip walls together at each corner. (See Figure 5)



NOTE: 5 x 5', 10 x 10' and 10 x 15' have one zippered wall for easy entry and exit. (See Figure 6)



NOTE: 10 x 20' has three zippered walls for easy entry and exit.

