



ULINE H-3437**ELECTRICAL PLUG PRONG LOCKOUT**1-800-295-5510
uline.comPara Español, vea página 2.
Pour le français, consulter la page 3.**OPERATION**

NOTE: Fits two prong plugs with or without ground.




NOTE: Can be used with lockout padlocks or lockout hasps.

1. Insert the plug prongs with or without ground. (See Figure 1)



NOTE: Insert fully to push out eyelet. (See Figure 2)



2. Insert the padlock and lock. (See Figures 3-4)




Figure 3





Figure 4


**BLOQUEADOR PARA
CLAVIJAS DE ENCHUFES
ELÉCTRICOS****FUNCIONAMIENTO**

NOTA: Se adapta a enchufes de dos clavijas con o sin tierra física.



NOTA: Se puede utilizar con candados para bloqueadores o con pestillos para bloqueadores.

1. Inserte las clavijas del enchufe con o sin tierra física. (Vea Diagrama 1)



2. Inserte el candado y asegure. (Vea Diagramas 3-4)

Diagrama 3






Diagrama 4



NOTA: Insértelo completamente para empujar el ojal hacia afuera. (Vea Diagrama 2)




ULINE H-3437

VERROU POUR BROCHES DE FICHES ÉLECTRIQUES

1-800-295-5510

uline.ca



FONCTIONNEMENT




REMARQUE : Convient aux fiches à deux broches avec ou sans broche de mise à la terre.




REMARQUE : Peut être utilisé avec des cadenas ou des moraillons verrouillables.

1. Insérez les broches de la fiche, qu'elle comprenne une broche de mise à la terre ou non. (Voir Figure 1)



REMARQUE : Insérez complètement pour faire sortir l'œillet. (Voir Figure 2)



2. Insérez le cadenas et verrouillez. (Voir Figures 3 et 4)

Figure 3




Figure 4

