



ASSEMBLY

3M protective headgear can only be used with 3M faceshields. This headgear/faceshield combination is designed to be used when the user is likely to come in contact with flying particles and liquid splash as long as use is consistent with all instructions, product warnings and eye and face protection regulations and standards.

1. Align the star shaped notches located on both ends of the face shield onto the headgear. (See Figure 1a)
2. Rotate the faceshield towards the headgear making sure that the faceshield is in front of the flange. (See Figure 1b)
3. Force the faceshield into the headgear until you hear it snap into place. (See Figure 2)



NOTE: To remove, pull back on the locking mechanism tab until the star shaped holes are aligned and remove the face shield.

