



ULINE S-22575 QUILTED PUFFER BAG

1-800-295-5510
uline.com




TOTE TO SHOULDER TRANSITION

1. Locate the reinforced area on one of the straps.
(See Figure 1)




2. If the reinforced area is covered by fabric, gently pull the strap through the fabric until the reinforced area is exposed in the opening at the top of the bag. (See Figure 2)



3. Pull the strap all the way up and out of the opening.
(See Figure 3)



NOTE: With time and use, the strap will soften.




ULINE S-22575

**BOLSA PUFFER
ACOLCHADA**


800-295-5510

uline.mx




TRANSICIÓN DE BOLSA DE MANO AL HOMBRO

1. Encuentre el área reforzada en una de las correas.
(Vea Diagrama 1)




2. Si la parte reforzada está cubierta con tela, jale ligeramente la correa a través de la tela hasta que el área reforzada quede expuesta en la abertura por la parte superior de la bolsa. (Vea Diagrama 2)




3. Jale la correa hasta arriba y hacia fuera de la abertura. (Vea Diagrama 3)




NOTA: La correa se suavizará con el uso y el tiempo.






TRANSITION DU SAC À POIGNÉE AU SAC À BANDOULIÈRE

1. Repérez la partie renforcée sur l'une des courroies.
(Voir Figure 1)



2. Si la partie renforcée est cachée, tirez avec soin sur la courroie à travers le tissu à l'ouverture sur le dessus du sac afin de dégager la partie renforcée.
(Voir Figure 2)



3. Tirez la courroie complètement vers le haut pour la dégager de l'ouverture. (Voir Figure 3)



REMARQUE : La courroie deviendra plus souple avec le temps et l'usage.

